

UTG GEN III Blank Firing Adaptor

Note:

1. Blank firing adaptor for Model 4 rifles is RED.

2. Blank firing adaptor for Model 4 carbines is YELLOW.

3. Every 50 rounds, check to make sure that the adaptor is still tight and secure. Clean up carbon build-up after each use.



Before installation, be sure to clear the weapon. Don not use tools to tighten adaptor.
HANDS ONLY.

Website: www.leapers.com

Telephone: 734-542-1500

E-mail: office@leapers.com

UTG GEN III Blank Firing Adaptor

1. Unscrew the bolt and slide it all the way out.



2. Hook the adaptor into the first groove of the compensator.



3. Slide the bolt into the compensator and **HAND TIGHTEN**. Do not use any tool.

